


GROUP - 15

AI Powered Allergen Detection System

Custom OCR for food safety - Allergen Detection
and Complex Food Ingredients simplifier



Team Members:

Kuldeep Choksi , Harshith Umesh

Ronit Naik , Kiran Deav

Introduction

Problem

- Approximately 32 million Americans have food allergies.
- Ingredient lists are hard to decipher quickly with confusing and hard to decipher ingredients names.

Solution

- Custom OCR for Food Ingredients Recognition using CNNs and Fuzzy Matching, to identify allergens and map complex ingredients to simpler synonyms.



Data Pipeline


Dataset

- 174,000+ character images (A-Z, a-z).
- Real-world images and variations with rotations and noise.

Preprocessing

- Grayscale the images for better detection.
- Binarization using Otsu's thresholding.
- Edge detection: Dilating image regions to find word boundaries.

Model Architecture



ABCDEFGHIJKLMNOPQRSTUVWXYZ

--> ['abcdefghijklmnopqrstuvwxyz']

abcdefghijklmnopqrstuvwxyz

--> ['qbcdefghlojkimnopqrstuvwxyz']

We achieved an accuracy of 95% for our Custom CNN.

Problems we faced

- Unable to identify punctuation characters.
- Images with coloured backgrounds.
- Initially trained on Macbook-only fonts which was impacting the accuracy.
- The similarity between “l” and “l” and “l”, “c” and “(”, “j” and “i”.
- Mapping OCR extracted words to our two datasets.



Post Processing

Candidate Generation:

- Trimming (removing extra characters).
- Ambiguous Character Replacement (i/l and r/f and i/j).

Fuzzy Matching:

- Using Levenshtein distance for candidate validation.

Allergen and Complex Ingredients Dataset Integration:

- Mapping candidates to a CSV of food ingredients and their simpler synonyms.

Results

Input Text:

INGREDIENTS: Enriched unbleached flour wheat flour, malted barley flour, ascorbic acid (dough conditioner, niacin, reduced iron, sucralose, folic acid) sugar, degermed yellow corn, salt, leavening (baking soda, sodium acid pyrophosphate) soybean, oil, honey powder, natural flavor, dextrose. CONTAINS: Wheat. May contain eggs, soy milk and tree nuts.

Extract Words using computer vision:

INGREDIENTS: Enriched unbleached flour wheat flour, malted barley flour, ascorbic acid (dough conditioner, niacin, reduced iron, sucralose, folic acid) sugar, degermed yellow corn, salt, leavening (baking soda, sodium acid pyrophosphate) soybean, oil, honey powder, natural flavor, dextrose. CONTAINS: Wheat. May contain milk, eggs, soy and tree nuts.

OCR Output and Allergen Detection

```
OCR Extracted Raw Words --> ['saitg', 'naturai', 'cdough', 'ingredientsnn', 'aeavenjng', 'aavo  
rj', 'conditionery', 'dextrosen', 'cbakjng', 'enrjched', 'njacjny', 'sodag', 'containsmm', 'unb  
ieached', 'reduced', 'sodjum', 'inny', 'wheatn', 'acfd', 'aourwheat', 'sucraiosey', 'pynphospha  
ted', 'may', 'contain', 'fiourj', 'foiic', 'maited', 'acjdd', 'eggsj', 'soybeanj', 'sugary', 'b  
ariey', 'soy', 'migk', 'oiij', 'degermed', 'fiourj', 'honey', 'and', 'ascorbjc', 'tree', 'powde  
rj', 'yenlow', 'nutsn', 'acjd', 'corny']
```

Allergens Warning:

OCR word 'wheatn' matched with FoodData CSV entry 'wheat'.

Class : Plant origin

Type : Cereal grain and pulse

Group: Cereal grain

Allergy: Gluten Allergy

OCR word 'fiourj' matched with FoodData CSV entry 'flour'.

Class : Plant origin

Type : Cereal grain and pulse

Group: Cereal grain

Allergy: Gluten Allergy

OCR word 'eggsj' matched with FoodData CSV entry 'eggs'.

Class : Animal origin

Type : Poultry

Group: Egg

Allergy: Poultry Allergy

Complex ingredients list simplification

Mapping Complex Ingredients to simpler synonyms:

OCR word 'dextrosen' matched with Complex Ingredient entry 'dextrose'.

Complex Ingredient : dextrose

Simpler Synonym : glucose

OCR word 'njacjny' matched with Complex Ingredient entry 'niacin'.

Complex Ingredient : niacin

Simpler Synonym : vitamin B3

OCR word 'sucraiosey' matched with Complex Ingredient entry 'sucralose'.

Complex Ingredient : sucralose

Simpler Synonym : artificial sweetener

Demo Link:

https://drive.google.com/drive/folders/1JMAX1FDDiB_UeX_ssKL0udnuIF0AnaGb

Recap

- Developed a Custom OCR using CNN to achieve 95 % accuracy.
- 174,000 character images for training, testing and validation.
- Incorporated allergen and complex ingredients synonym datasets.
- We integrate Deep Learning with Heuristic Post-Processing.

Future Scope

- Build a Mobile Application with an easy to use user interface where a user can click a picture and do the food label analysis.
- Expand the allergen dataset.
- Expand the complex ingredient to simple synonym dataset.